

# Instructions for the correct storage and maintenance of Lenz lithium-ion batteries and regeneration of not correctly stored batteries

## Storage:

1. Before storing discharge batteries and semi re-charge (half charge) (see instructions) – DO NOT FULLY CHARGE. Turn off the battery and unplug the charger.
2. Cool and dry storage at 5 ° C to 20 ° C.
3. Basically avoid prolonged disuse. In the case of long-term storage discharge the batteries and semi re-charge (half charge) them every six month.
4. Charge batteries fully before each use.

Proper storage of the battery maximizes battery performance and life. For more information, see the Instructions

## Regeneration:

If you have stored the batteries over the summer months or a longer period without following above instructions, we recommend that you discharge and charge the batteries fully 3 times before the first use after storage.

To do that connect the battery to the sock / vest / bandage or sole and discharge them using the highest setting. Then recharge fully to have the product ready for use.

In case of any questions please contact us at our service address:

SturiaTronic Projektmanagement GmbH  
Ressavarstrasse 12-14  
8230 Hartberg | Austria

Tel: +43 (0) 3332 20302  
Fax: +43 (0) 3332 20302 – 6  
Mail: [service@sturiatronic.com](mailto:service@sturiatronic.com)

